



PRINTING INSTRUCTIONS

Print at full-scale and place tools over the paper to verify the fit.


Option 1: Print this page full-scale on a large-format printer
(E-Size, 44 inches X 34 inches).

Option 2: Print page 2 - 7 on 8-1/2 X 11 inch paper and assemble.

THE INFORMATION CONTAINED ON THIS DRAWING
IS THE SOLE PROPERTY OF FOAMFIT TOOLS AND
MAY NOT BE USED WITHOUT PERMISSION.
Copyright 2026 FoamFit Tools



PART NUMBER
F-06560-R



PART NUMBER

F-06560-R

PAGE (ROW-COLUMN)

1-1

Numbering starts
from the front
left corner.


DATE CREATED

30 JUL 2026

DATE REVISED

FoamFit Tools

Print on Letter at 100%



PART NUMBER

F-06560-R

PAGE (ROW-COLUMN)

1-2

Numbering starts
from the front
left corner.


DATE CREATED

30 JUL 2026

DATE REVISED

FoamFit Tools

Print on Letter at 100%



PART NUMBER

F-06560-R

PAGE (ROW-COLUMN)

2-1

Numbering starts
from the front
left corner.


DATE CREATED

30 JUL 2026

DATE REVISED

FoamFit Tools

Print on Letter at 100%



PART NUMBER

F-06560-R

PAGE (ROW-COLUMN)

2-2

Numbering starts
from the front
left corner.


DATE CREATED

30 JUL 2026

DATE REVISED

FoamFit Tools

Print on Letter at 100%



PART NUMBER

F-06560-R

PAGE (ROW-COLUMN)

3-1

Numbering starts
from the front
left corner.

DATE CREATED

30 JUL 2026

DATE REVISED

FoamFit Tools

Print on Letter at 100%



PART NUMBER

F-06560-R

PAGE (ROW-COLUMN)

3-2

Numbering starts
from the front
left corner.

DATE CREATED

30 JUL 2026

DATE REVISED

FoamFit Tools

Print on Letter at 100%